



Alpine Industries
27 Selvage St.
Irvington, NJ 07111
Tel: 973 601 5105
Fax: 973 854 8650

Single-Roll Jumbo Bath Tissue Dispenser

450-GRY, 450-WHI

Installation

1. Please choose a vertical, clean and smooth mounting surface.
2. Make sure there is enough room above dispenser to access cover lock key.
3. Unlock the front cover and use the back plate for the drill marks and mark the 3 drill locations.
4. Drill 3 holes at marked locations and insert 3 plastic anchors into drilled holes.
5. The installation should be done with a flat washer (not supplied) between the head of the screw and inside back of the dispenser.
6. Complete the installation.

Specifications

Roll Diameter: 9 inches
Core Diameter: 2 ½ inches