

# OPTIMIZER™ ADJUSTABLE DISH DOLLY ASSEMBLY INSTRUCTIONS

PRODUCT NUMBERS: ADD4 & ADD6




Figure 1  
cutaway showing slot




Figure 2

1. Following the layout for the size of plate/platter that you are using (see the back of this page), place a divider (with the bolt on the bottom) into one of the slots (see Figure 1). In order to secure the plates/platters properly, make sure the divider is facing the correct way shown in the layout (see other side).
2. Place a single plate/platter between the divider and the wall of the dish dolly (see Figure 2).
3. Reaching under the cart, place a washer and knob onto the divider bolt and twist a few turns (see Figure 1). While pushing the bottom of the divider lightly against the plate/platter, turn the knob until the divider is tight (see Figure 2).
4. Repeat steps 1 through 3 for each of the remaining stack positions illustrated in the layout.
5. Fill each position with plates/platters.



ADD4 Layout for  
9-7/8" to 10-5/8" plates

Many other combinations can be created when combining different size plates/platters. For these combinations, follow these steps:

1. Determine the best layout by placing plates/platters in the dolly and placing dividers loosely in the slots. Move the plates/platters and dividers around to create the best fit. Usually, the divider will be turned so that the wider side of the divider is against the plate/platter.
2. After determining the best layout, secure the dividers as in step 3 above.
3. Fill each position with plates/platters.

P.O. Box 53006  
Oklahoma City, Oklahoma 73152-3006  
(405) 475-5600 • FAX (405) 475-5607  
1-800-654-8210  
Web Site: [www.carlislefsp.com](http://www.carlislefsp.com)  
#104803213 - 1/05


European Distribution Center:  
Edisonstraat 84, P.O. Box 110  
6900 AC Zevenaar, The Netherlands  
Tel +31/(0)316-596550 • Telex 45642  
FAX +31/(0)316-340168

**CARLISLE**  
FoodService Products


# OPTIMIZER™ ADJUSTABLE DISH DOLLY ASSEMBLY INSTRUCTIONS

The following diagrams show the standard layouts for plates from 5-1/2" to 12-1/2" and platters from 9-1/2" by 7-1/4" to 13-1/2" by 10-1/2". Locate the desired plate/platter size(s) in the ranges below each layout. Many other options are available if different plate/platter sizes are used together (see the bottom of the instructions on the other side of this page).


**NOTE:** When setting up the dish dolly, be sure to turn the dividers as indicated in each layout.




Layout for 11-3/8" to 12-1/2" plates and 13-1/2" by 10-1/2" platters




Layout for 10-3/4" to 11-1/4" plates




Layout for 9-7/8" to 10-5/8" plates




Layout for 8-3/8" to 9-3/4" plates



Layout for 8" to 8-1/4" plates



Layout w/2 Additional Dividers for 5-1/2" to 7-7/8" plates



Layout for 12" by 9-1/4" to 9-1/2" by 7-1/4" platters

P.O. Box 53006  
Oklahoma City, Oklahoma 73152-3006  
(405) 475-5600 • FAX (405) 475-5607  
1-800-654-8210  
Web Site: [www.carlislefsp.com](http://www.carlislefsp.com)  
#104803213 - 1/05

European Distribution Center:  
Edisonstraat 84, P.O. Box 110  
6900 AC Zevenaar, The Netherlands  
Tel +31/(0)316-596550 • Telex 45642  
FAX +31/(0)316-340168

**CARLISLE**  
FoodService Products