



Rim Fruit  
**9001C330**  
 D 6 1/2" H 1 3/4" (8 1/2 oz)  
**9001C329**  
 D 5 1/4" H 1 1/4" (4 1/2 oz)



Axis Bowl  
**9001C487** D 8" H 4" (38 oz)  
**9001C488** D 6" H 3" (16 oz)  
**9001C489** D 3 1/2" H 2" (4 oz)



Mandarin Bowl  
**9001C247** D 6 1/4" H 3 1/4" (28 oz)  
**9001C242** D 5" H 2 3/4" (16 oz)  
**9001C248** D 4 1/2" H 2 1/4" (9 oz)  
**9001C249** D 4" H 2" (7 oz)



Mandarin Bowl  
**9001C240**  
 D 3 3/4" H 1 3/4" (4 1/2 oz)



Dish  
**9001C245**  
 D 4" H 3/4" (3 oz)



Dish  
**9001C246**  
 D 2 3/4" (1 oz)



Crescent Salad Plate  
**9001C063**  
 L 8" W 4 1/2"



Soup Cup Stacking  
**9001C312** Unhandled L 4 1/4" H 2 1/4" (10 oz)  
**9001C311** Handled L 6" H 2 1/4" (10 oz)  
 Saucer Single Well  
**9001C318** D 6" (Fits C312, C311)



Sugar/Bouillon Cup  
**9001C335** D 4" H 2 1/4" (8 oz)  
 Saucer Single Well  
**9001C318** D 6"



Tall Cup Unhandled  
**9001C355**  
 D 2 1/2" H 2 1/8" (3 oz)



Spoon  
**9001C244**



Stacking Cup  
**9001C331** L 4 1/8" H 2 1/2" (7 1/2 oz)  
**9001C332** L 3 7/8" H 2 3/8" (6 oz)  
**9001C333** L 3 1/4" H 1 3/4" (3 oz)  
 Saucer Single Well  
**9001C318** D 6" (Fits C331, C332)  
**9001C317** D 4 5/8" (Fits C333)



Low Cup  
**9001C152** L 5 1/8" H 2 5/8" (12 oz)  
**9001C189** L 4 5/8" H 2 3/8" (8 oz)  
**9001C190** L 3 3/8" H 1 3/4" (3 oz)  
 Saucer Single Well  
**9001C318** D 6" (Fits C152, C189)  
**9001C317** D 4 5/8" (Fits C190)



Fine Cup  
**9001C174** L 5 1/8" H 2 3/4" (12 oz)  
**9001C173** L 4 5/8" H 2 1/2" (8 oz)  
**9001C172** D 3 3/8" H 1 7/8" (3 oz)  
 Fine Saucer  
**9001C168** D 6 1/2" (Fits C174, C173)  
**9001C167** D 4 5/8" (Fits C172)



Tall Cup  
**9001C338** L 4 1/4" H 2 7/8" (8 oz)  
 Saucer Single Well  
**9001C318** D 6"



Rococo Can Cup  
**9001C1114** L 4 3/8" H 2 3/8" (8 oz)  
**9001C1116** L 3 1/2" H 2 3/8" (4 oz)  
 Rococo Can Saucer  
**9001C1115** D 6 1/2" (Fits C1114)  
**9001C1117** D 4 5/8" (Fits C1116)