




Round Stackable Roll Top Chafing Dish
5370S531 L 21" W 17" H 19" (6 3/4 qts)



Round Food Pan
5370S547 D 15 1/8" H 3" (6 3/4 Qts)
(For S531, S542, S471)

Round Water Pan
5370S546 L 16 5/8" W 15 3/4" H 4"
w/Channel for Electric Heating Unit
(For S531, S542, S471)



Fuel Holder
5370S408



Oblong Stackable Roll Top Chafing Dish
5370S530 L 27" W 22" H 19" (8 1/2 qts)



Oblong Food Pan
5370S545 L 21" W 12 7/8" H 2 1/2" (8 1/2 Qts)
(For S530, S541, S470)

Oblong Water Pan
5370S544 L 23" W 14 5/8" H 4"
w/Channel for Electric Heating Unit
(For S530, S541, S470)



Fuel Holder
5370S408




Chafing Dish Round
5370S542 D 20" H 18" (6 3/4 qts)



Round Food Pan
5370S547 D 15 1/8" H 3" (6 3/4 Qts)
(For S531, S542, S471)

Round Water Pan
5370S546 L 16 5/8" W 15 3/4" H 4"
w/Channel for Electric Heating Unit
(For S531, S542, S471)



Fuel Holder
5370S408



Soup Station Accessories for S531 & S542
Soup Station Lid for Round Soup Station
5370S549 D 14 1/8" (Fits S546 Water Pan)
Soup Bucket
5370S550 D 9 1/8" H 8 3/4" (3 3/4 qts)



Chafing Dish Rectangle
5370S541 L 26" W 17 3/4" H 16 3/4" (8 1/2 qts)




Oblong Food Pan
5370S545 L 21" W 12 7/8" H 2 1/2"
(8 1/2 Qts)
(For S530, S541, S470)

Oblong Water Pan
5370S544 L 23" W 14 5/8" H 4"
(For S530, S541, S470)



Fuel Holder
5370S408



Soup Station Accessories for S530 & S541
Soup Station Lid for Rectangle Soup Station
5370S548 L 20 1/8" W 12 1/4" (Fits S544 Water Pan)
Soup Bucket
5370S550 D 9 1/8" H 8 3/4" (3 3/4 qts)



Storage Box
5370S215 L 31 3/4" W 23 1/2" H 18 1/2" (For S530, S541)