

RENE OZORIO *aura*

Aura was created to meet the demands of modern food presentation. The range is built around three alluring shapes.

AURA BROAD RIM The wide angled rims and small wells focus on smaller portions.

AURA MID RIM An elegant shape combining a shallow bowl with flat rim to create a delicate and contemporary feel.

AURA BANQUET RIM A perfect banqueting range delivering style and functionality.



6300P001
Rim Plate **D** 12"
6 1/4" well



6300P007
Rim Coupe Plate **D** 12"
6 3/4" well



6300P005
Rim Plate **D** 12"
4 3/4" well



6300P015 Broad Rim Plate **D** 11" (5 1/4" well)
6300P016 Broad Rim Plate **D** 9 1/2" (4 3/4" well)
6300P017 Broad Rim Plate **D** 7 7/8" (4 1/8" well)
6300P004 Broad Rim Plate **D** 6 1/4" (4 1/4" well)



6300P010 Mid Rim Plate **D** 10 1/2" (7 1/2" well)
6300P011 Mid Rim Plate **D** 9 1/2" (6 1/4" well)
6300P012 Mid Rim Plate **D** 8" (5 1/4" well)
6300P013 Mid Rim Plate **D** 6 3/4" (4" well)



6300P006 Banquet Rim Plate **D** 12"
6300P307 Banquet Rim Plate **D** 11 1/4"
6300P302 Banquet Rim Plate **D** 10 3/4"
6300P303 Banquet Rim Plate **D** 9 1/2"
6300P304 Banquet Rim Plate **D** 8 3/4"
6300P305 Banquet Rim Plate **D** 6 3/4"
6300P306 Banquet Rim Plate **D** 6"



6300P373 Coupe Plate **D** 11 3/4"
6300P374 Coupe Plate **D** 9 7/8"
6300P375 Coupe Plate **D** 6 1/2"



6300P008
Pasta Plate **D** 12"
5 1/2" well



6300P112 Oval Platter **L** 14 1/8"
6300P380 Oval Platter **L** 11"



6300P310 Race Track Oval Platter L 17 3/4" W 13 1/2"
6300P311 Race Track Oval Platter L 14 3/4" W 11 1/4"
6300P312 Race Track Oval Platter L 12 1/2" W 9 1/2"
6300P313 Race Track Oval Platter L 10" W 7 3/4"
6300P314 Race Track Oval Platter L 8 1/4" W 6 1/4"
6300P315 Race Track Oval Platter L 6 1/4" W 4 5/8"



6300P386 Noodle Bowl D 7 1/4" H 3 3/8" (32 oz)
6300P387 Noodle Bowl D 5 3/4" H 2 5/8" (13 1/2 oz)



6300P062 Flared Bowl D 11 3/4" H 2 7/8" (24 oz)
6300P063 Flared Bowl D 10 1/2" H 2 5/8" (19 oz)



6300P070 Deep Coupe Bowl D 12" H 2" (74 oz)
6300P071 Deep Coupe Bowl D 11" H 2" (54 oz)
6300P072 Deep Coupe Bowl D 9" H 1 3/4" (32 oz)



6300P050 Laksa Bowl D 9 3/4" H 3 1/2" (16 oz)
6300P051 Laksa Bowl D 8" H 3" (7 oz)



6300P044 Bowl D 7 7/8" H 3 3/8" (33 oz) (fits Cloche P045)
6300P239 Soup Bowl Underliner for **6300P044**
6300P043 Bowl D 6 5/8" H 2 3/4" (19 oz) (fits Cloche P042)
6300P040 Bowl D 5 1/2" H 2 3/8" (10 oz) (fits Cloche P041)
6300P184 Soup Bowl Underliner for **6300P040**
6300P239 Soup Bowl Underliner for **6300P043**



6300P054 Soup Plate
 D 11 5/8" H 2" (fits Cloche P066)
6300P066 Cloche (fits **6300P054**)



6300P064 2 Handle Cream Soup L 6 1/4" H 2 1/2" (10 oz)
6300P069 Cream Soup w/out Handle L 4 5/8" H 2 1/2" (10 oz)
6300P457 Aura Universal Saucer D 6 1/2"
6300P182 Saucer D 7"



6300P065
 Rim Soup D 9 1/2" H 1 5/8" (18 oz)



6300P055
 Soup Cereal Bowl D 7" H 2 1/8" (10 oz)



6300P350 Rice Bowl D 4 1/2" H 2 1/4" (10 oz)
6300P351 Rice Bowl D 4 1/8" H 2 1/8" (8 1/2 oz)
6300P352 Coupe Saucer D 6 1/2"



6300P067
 Footed Bowl
 D 5 1/8" H 2 1/8" (12 oz)



6300P248
 Slant Bowl D 3 1/2" H 2"
 max (2 oz) (fits Rect. Tray **P249**)



6300P049
 Noodle Bowl
 D 9" H 3 3/8" (32 oz)



6300P162
 Sauce Dish
 D 4 1/4" H 7/8" (2 3/4 oz)



6300P353 Large Coupe Sauce Dish
 D 4 3/8" H 1 1/8" (3 1/2 oz)
6300P354 Small Coupe Sauce Dish
 D 3 1/2" H 1" (1 oz)



6300P255
 Sauce Bowl
 D 3" H 7/8" (1/2 oz)



6300P256
 Sauce Dish
 D 3" H 3/4" (1/2 oz)



6302P247 Spoon L 5 1/8"
6300P357 Spoon Rest



6300P151 Sugar Bowl D 4 1/4" H 2" (8 oz)
6300P182 Sugar Bowl Saucer D 7"



6300P144
 Teacup w/o handles
 D 3 1/4" H 2 3/8" (5 1/2 oz)



6300P257
 Small Sauce Pot
 D 1 3/4" H 1 7/8" (2 oz)



6300P370
 Soy Sauce/Vinegar Pot w/Lid
 L 3 5/8" H 4 3/8" (4 1/2 oz)
6300P389 Lid



6300P366
 Chili Bowl w/lid
 D 3" H 2 1/8" (3 1/2 oz)
6300P367 Lid




6300P368
 Small Spice Spoon
 L 4 1/2"



6300P359
 Chop Stick Rest
 L 2 3/4" W 1/2"



6300P113
 Olive Oil Dish
 L 4 1/4" W 2 7/8"



6300P114
 Sugar Packet Holder
 L 4 1/8" W 2 3/4" (6 oz)



6300P068
 Round Tray D 5 3/4"



6300P160 Salt (1 hole)
6300P161 Pepper (5 hole)



6300P149
Unhandled Creamer L 3 1/4" H 2 7/8" (5 oz)
6300P150
Unhandled Creamer L 2 1/2" H 2 3/8" (2 oz)
6300P147
Unhandled Creamer L 1 1/2" H 1 5/8" (1/2 oz)

6300P154 Coffee Pot w/lid (22 oz)
6300P159 Lid for **6300P154**
6300P152 Coffee Pot w/lid (12 oz)
6300P157 Lid for **6300P152**

6300P155 Tea Pot w/lid (20 oz)
6300P199 Lid for **6300P155**
6300P153 Tea Pot w/lid (15 oz)
6300P197 Lid for **6300P153**

6300P148
Handled Creamer
L 5" H 3 3/8"
(8 1/2 oz)



6300P190
Can Cup
L 4" H 3" (8 oz)

6300P194 Stacking Mug
L 4 5/8" H 4 1/2" (15 1/4 oz)
6300P193 Stacking Mug
L 4 1/2" H 3 7/8" (10 1/4 oz)

6300P189 Tall Cup L 4 5/8" H 2 3/8" (5 oz)
6300P180 Saucer D 6 1/4"

6300P186
Stacking Cup L 4 1/8" H 2 5/8" (8 oz)
6300P180 Saucer D 6 1/4"



6300P192 Tea Cup L 4 1/2" H 3" (6 3/4 oz)
6300P183 Saucer D 6 1/2" (Fits **P186**, **P189**, **P192**)



6300P187 A.D. Cup
L 3 5/8" H 2 1/8" (2 1/2 oz)
6300P181 AD Saucer D 4 5/8"



6300P191 Mug L 4 7/8" H 3 3/4" (8 oz)
6300P363 Coupe Saucer D 6 1/2"



6300P171 Low Cup Breakfast
L 5 5/8" H 2 5/8" (13 1/2 oz)
6300P457 Aura Universal Saucer D 6 1/2"
(Fits **P064**, **P069**, **P171**, **P174**)
6300P172 Saucer For Low Cup Breakfast Cup D 7 1/8"



6300P174 Low Cup Coffee (8 1/2 oz)
6300P457 Aura Universal Saucer D 6 1/2"
(Fits **P064**, **P069**, **P171**, **P174**)
6300P175 Saucer D 6 1/4" (For **P174**)



6300P176 Low Cup Ad (3 3/8 oz)
6300P177 Saucer D 5 3/4" (For **P176**)