

STEELITE PERFORMANCE *simplicity cookware*



Casserole
11010337 (104 oz)
11010334 (75 oz)
 Casserole Lid
11010338 (Fits 0337)
11010335 (Fits 0334)



Oblong Roaster
11010331 L 14" W 12" (125 oz)
11010342 L 12" W 10" (80 oz)



Square Roaster
11010329 L W 10" (65 oz)



Oval Eared Dish
11010321 L 13 1/2" W 7 1/2" (36 1/2 oz)
11010320 L 12" W 6 1/2" (27 1/2 oz)
11010319 L 9 1/2" W 5 1/2" (12 1/2 oz)
11010318 L 8" W 4 1/2" (6 1/2 oz)



Presentation Pan
11010866 D 10" (33 1/2 oz)



Round Eared Dish
11010317 L 8 1/2" (27 1/2 oz)
11010316 L 7 1/2" (19 oz)
11010191 L 5 3/4" (6 1/2 oz)



Oval Sole Dish
11010326 L 11" W 7 1/2" (52 oz)
11010327 L 8 1/2" W 5 1/2" (19 oz)
11010315 L 6 1/4" W 4 1/2" (10 1/2)



Soup Bowl Covered Complete
11010828 D 4 7/8" L 6 1/4" H 3" (15 oz)
11010829 Cover for Soup Bowl
 Soup Bowl Base
1101B828 D 4 7/8" L 6 1/4" H 2 1/4" (15 oz)



Oval Baker
11010400 L 6 1/4" H 2" (13 oz)



Lipped Oval Baker
11010328 L 6 1/4" (13 oz)



Rectangular Tray
11010366 L 6 1/2" W 4 3/4" (17 1/2 oz)



Stack Bowl
11010308 D 8 1/4" H 3" (68 oz)
11010309 D 6 5/8" H 2 3/8" (31 oz)
11010310 D 5" H 1 7/8" (13 oz)



Decanter
11010282 L 7 1/2" H 19 3/8" (32 oz)
11010283 L 5 7/8" H 9" (16 oz)



Butter Block
11010332 H 1/2" (1 oz)



Ramekin
11010324 D 3 1/4" H 1 7/8" (5 oz)
11010323 D 3" H 1 3/4" (3 oz)
11010322 D 2 1/2" (2 1/2 oz)