


INSTRUCTION MANUAL

Light-Duty Immersion Blender



Model: ACIB17508 – 175W (1/2HP), 8” (203mm) SHAFT

Read this manual thoroughly before using and save it for future reference.

Admiral Craft Equipment Corps.
3355 Enterprise Drive – Suite 160
Ft. Lauderdale, FL 33331
Phone: 800.223.7751 Fax: 800.447.7751

IMPORTANT SAFEGUARDS

Before using the electrical appliance, the following basic precautions should always be followed including the following:

1. Read all instructions.
2. Before using check that the voltage of wall outlet corresponds to the one shown on the rating plate.
3. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or is dropped or damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair or electrical or mechanical adjustment.
4. If the supply cord is damaged it must be replaced by the manufacturer or a authorized service agent or a qualified technician in order to avoid a hazard.
5. Always disconnect the blender from the supply if it is left unattended and before assembling, disassembling, or cleaning.
6. Do not let cord hang over edge of table or hot surface.
7. Do not immerse upper part of blender into water as this would give rise to electric shock.
8. Close supervision is necessary when your appliance is being used near children or infirm persons.
9. Avoid contacting moving parts.
10. Keep hands and utensils out of container while blending to reduce the risk of severe injury to persons or damage to the blender. A scraper may be used but must

be used only when the blender is not running.

12. The use of accessory not recommended by the manufacturer may cause injuries to persons.

13. Do not operate the appliance for other than its intended use.

14. Children should be supervised to ensure that they do not play with the appliance.

15. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory, or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised.

16. The use of accessory not recommended by the manufacturer may cause injuries to persons.


17. The metal blades are extremely sharp, please handle carefully.

18. Switch off the appliance and disconnect from supply before changing accessories or approaching parts that move in use.


19. Always hold the blending rod instead of cutting edge when handling and cleaning the blade.

20. Be care of potential injury from misuse.

SAVE THESE INSTRUCTIONS FOR COMMERCIAL USE ONLY



KNOW YOUR COMMERICAL HAND BLENDER



USING YOUR BLENDER

Before the first use, clean the blender according to the section of “**Quick cleaning**”.

The duration running unit without load can't exceed 15s.

Important: Blades are very sharp, handle with care. Ensure that the hand blender is unplugged from the power outlet before assembling or removing attachments.

Operation instruction

Important: Max operation duration per cycle cannot exceed 3 minute, and 1 minute

rest time must be maintained at two consecutive cycles.

1. To assemble the detachable blending rod with the motor unit, turn the blending rod clockwise until it is tightened. To disassemble, just turn in the adverse direction.
2. Simply plug the hand blender to power outlet.
3. Put the food to be blended into a bowl.
4. Lower the hand blender into food. Then press and hold the **Low speed** button or **High speed** button to start operating.
5. To stop the hand blender, release the **Low speed** button or **High speed** button.

CLEANING AND MAINTENANCE

1. Unplug the appliance and remove the blending rod before cleaning.

Note: Do not immerse the detachable blending rod in water, as prolonged immersion in water will flush the lubricating oil out of the bearing.

2. Wash the blending rod under running water, and do not use abrasive cleaner or detergents. After cleaning, place it upright to drain out any remaining water. The blending rod is dishwasher safe.

3. Wipe the motor unit with a damp cloth. Never immerse it in water for cleaning as electric shock may occur.

4. Dry thoroughly.

Caution: Blades are very sharp, handle with care.

Quick cleaning

Between processing tasks, hold the hand-held blender in the cup half filled with water, ensuring the blending head is immersed in the water, and turn on the blender to blend for a few seconds.

