



CATALOG OF REPLACEMENT PARTS


MB BREAD SLICER



Table of Contents

5 RACK ARRANGEMENT
7 CRANKSHAFT, MOTOR, AND COVER
9 OUTER FRAME ASSEMBLY
11 INNER FRAME
13 SWITCH MECHANISM
15 BLADE AND FRAME ASSEMBLY
17 CAMS, LINKAGE, AND SCRAP PAN

16 01-404575-01041 Brush - Cleaning
PART NOT ILLUSTRATED




PL-59513

RACK ARRANGEMENT

RACK ARRANGEMENT


ILLUS.	PART NO.	NAME OF PART	AMT.
1	01-402175-00210	Mach. Screw Hex Hd.....	2
2	01-402275-03055	Lockwasher.....	2
3	01-4A7324-0001D	Trough Assy. - Moveable (1/2 In.).....	1
4	01-4A7324-00012	Trough Assy. - Moveable (7/16 In.).....	1
5	01-4A7324-00013	Trough Assy. - Moveable (3/8 & 3/4 In.).....	1
6	01-4A7324-0002E	Trough Assy. - Stationary (1/2 In.).....	1
7	01-43A732-4-10C	Trough Assy. - Stationary (7/16 In.).....	1
8	01-4A7324-00014	Trough Assy. - Stationary (3/8 & 3/4 In.).....	1
9	01-402175-00423	Cap Screw 1/4 x 3/8 Slotted Rd. Hd., Type TT.....	2
10	01-403875-00163	Cover (White).....	1
11	01-402275-03065	Lockwasher.....	2
12	01-402175-00231	Cap Screw Hex Hd.....	2
13	01-403475-01033	Insert (Cut-Through) (1/2).....	1
14	01-403475-01034	Insert (Cut-Through) (7/16).....	1
15	01-403475-01035	NLA - Obsolete--Insert (Cut-Through) (3/8 & 3/4).....	1
16	01-404575-01041	Brush - Cleaning.....	1



CRANKSHAFT, MOTOR, AND COVER

CRANKSHAFT, MOTOR, AND COVER

ILLUS.	PART NO.	NAME OF PART	AMT.
PL-59516			
1	01-404575-00885	Hood Assy. (White).....	1
2		Cover Assy. (Chrome) (Part no longer available, order Item 1).....	1
3	01-403175-00537	Label - Warning.....	1
4	01-402175-00189	Mach. Screw 10-32 Truss Hd.....	1
5	01-402275-03065	Lockwasher.....	1
6	01-402275-03061	Washer.....	1
7	01-402175-00120	Nut 5/16-24 Hex.....	1
8	01-407327-0004B	Spacer - Rubber Hood.....	1
9	01-402175-00120	Nut 5/16-24 Hex.....	1
10	01-402275-03065	Lockwasher.....	1
11	01-402375-00120	V-Belt.....	1
12	01-403775-00346	Pulley - Crankshaft.....	1
13	01-402175-05163	Set Screw 5/16-18.....	1
14	01-402375-00010	Bearing - Ball.....	1
15	01-402275-04826	Key 3/16 x 3/16 x 2.....	1
16	01-404375-00176	Shaft Assy. - Crank.....	1
17	01-402375-00010	Bearing - Ball.....	1
18	01-404975-00049	Connecting Rod & Bearing Assy.....	1
19	01-402175-07152	Set Screw 1/4-20 x 5/16.....	1
20	01-402275-00388	Shim.....	1
21	01-402175-07152	Set Screw 1/4-20 x 5/16.....	1
22	01-402275-00388	Shim.....	1
23	01-402275-03441	Pin - Cotter.....	2
24	01-402175-00256	Cap Screw 1/4-28 x 1 Hex Hd.....	1
25	01-409799	Cap Screw 5/16-24.....	1
26	01-404675-00689	Bearing Assy. - Crankshaft (Incls. Item 27).....	1
27	01-403775-00348	Bracket - Crankshaft.....	1
28	WL-003-38	Lockwasher 1/4 Helical.....	1
29	01-403375-00954	Pin - Connecting Rod.....	1
30	01-402275-00388	Shim.....	1
31	01-403875-00121	Bushing - Rubber.....	1
32	01-402275-00249	Bushing (Brass).....	1
33	01-404675-00865	Yoke Assy. (Incls. Items 31, 32, 35, & 36).....	1
34	01-402175-00226	Cap Screw 1/4-28 x 1-1/4 Hex Hd.....	1
35	01-402275-00249	Bushing (Brass).....	1
36	01-403875-00121	Bushing - Rubber.....	1
37	01-402275-00388	Shim.....	1
38	01-404675-00690	Crankshaft & Bracket Assy. (Incls. Items 14, 16, 17, & 19 thru 37).....	1
39	01-404675-01156	Motor (Incls. Items 40 thru 48).....	1
40	01-402275-03065	Lockwasher.....	4
41	01-402175-03061	Cap Screw 5/16-18 x 5/8 Hex Hd.....	4
42	01-403475-01026	Mount - Motor (Spirod).....	2
43	01-404575-01036	Mount - Motor.....	1
44	01-404175-00731	Motor (115/230 V., 50/60 Hz., 1 Ph.).....	1
45	01-402175-05163	Set Screw 5/16-18.....	1
46	01-402275-00087	Clamp - Motor.....	2
47	01-402275-04822	Key 3/16 x 3/16 x 1.....	1
48	01-402375-00118	Pulley - Motor (Incls. Set Screw).....	1
49	01-404175-00304	Cord (Switch to Motor).....	1
50	01-402275-00390	Spacer.....	AR




PL-59515

OUTER FRAME ASSEMBLY

OUTER FRAME ASSEMBLY


ILLUS. PL-59515	PART NO.	NAME OF PART	AMT.
1	01-404575-00911	NLA - Obsolete--Frame Assy. - Side (LH).....	1
2	01-402175-00198	Set Screw 1/4-28 x 5/16.....	1
3	01-402175-05152	Set Screw 1/4-20.....	1
4	01-402175-01261	Bolt 5/16-18 x 3/4 Hex Hd.....	4
5	01-402275-03065	Lockwasher.....	5
6	01-408748	Mach. Screw Hex Hd.....	2
7	01-408595	Spring - Extension.....	1
8	01-407320-0004F	Nut - Taper.....	1
9	01-403375-01186	Bracket Assy. - Spring.....	1
10	01-402175-00194	Mach. Screw Hex Hd.....	1
11	01-403275-00115	Washer (41/64) Special.....	1
12	01-407320-0003D	Bumper.....	1
13	01-402275-01060	Washer.....	4
14	01-402175-05060	Nut 5/16-18 Hex.....	4
15	01-407320-0001R	Lock Nut - Adjustable Foot.....	4
16	01-402175-00120	Nut 5/16-24 Hex.....	2
17	01-402225	Bolt Sq. Hd.....	1
18	01-402175-00173	Nut.....	1
19	01-408583	Bolt Hex Hd.....	1
20	01-4A3000-00001	Foot - Rubber.....	4
21	01-402275-03061	Washer.....	1
22	01-407320-00003	Brace Assy. - Rear.....	1
23	01-407320-0001Q	Foot - Adjusting.....	4
24	01-402175-00189	Mach. Screw 10-32 Truss Hd.....	1
25	01-407325-0005E	NLA - Obsolete--Clamp.....	1
26	01-402175-00186	Screw Slotted Rd. Hd.....	1
27	01-402175-00210	Mach. Screw Hex Hd.....	1
28	01-402275-03061	Washer.....	1
29	01-402175-00137	Thin Nut 3/8"-24, 0.227 - 0.210" thick.....	2
30	01-407306-0003G	Screw - Pivot Plunger.....	1
31	01-404575-00346	Dashpot Assy.....	1
32	01-403375-01188	Support - Plunger Bottom.....	1
33	01-408456	Screw - Pivot Plunger.....	1
34	01-402175-00214	Nut 1/4-28 Hex.....	1
35	01-404675-00928	Brace Assy. - Frame.....	1
36	01-402275-03055	Lockwasher.....	5
37	01-402175-00200	Cap Screw 1/4-28 x 1/2 Hex Hd.....	1
38	01-407324-00003	Support - Stationary Trough.....	1
39	01-402175-00188	Cap Screw.....	1
40	01-407324-0004B	Stop - Operating Handle.....	1
41	01-402175-00175	Cap Screw Hex.....	1
42	01-404575-00908	Frame Assy. - Side (RH).....	1
43	01-402175-00214	Nut 1/4-28 Hex.....	1
44	01-403575-00203	Brace - Front Frame.....	1
45	01-410297-00030	Shim.....	1
46	01-407320-0003D	Bumper.....	1
47	01-408456	Screw - Pivot Plunger.....	1
48	01-402175-00200	Cap Screw 1/4-28 x 1/2 Hex Hd.....	1
49	01-400375-01189	Brace - Stationary Trough.....	1
50	WL-003-38	Lockwasher 1/4 Helical.....	1
51	01-402175-03051	Cap Screw 1/4-20 x 1/2 Hex Hd.....	1
52	01-402175-00214	Nut 1/4-28 Hex.....	1
53	01-402175-00256	Cap Screw 1/4-28 x 1 Hex Hd.....	1
54	01-404975-00418	Stand (SST).....	1
55	01-404975-00052	Leg Extension (4 In.) (Incls. Items 20, 56, 57, & 58).....	4
56	01-402175-03764	Screw.....	4
57	01-402275-03071	Washer.....	4
58	01-403375-00018	Extension - Foot.....	4



INNER FRAME

INNER FRAME


ILLUS. PL-59511	PART NO.	NAME OF PART	AMT.
1	01-404575-00796	Bracket Assy. (White).....	1
2		Screw.....	2
3	01-403475-01038	Trough - Bagging.....	1
4	01-402175-05152	Set Screw 1/4-20.....	1
5	01-408469	Bolt Hex Hd.....	1
6	01-402175-00198	Set Screw 1/4-28 x 5/16.....	1
7	01-407103-00001	Bushing - Oilite.....	1
8	01-408482	Nut.....	1
9	01-402175-00078	Retaining Ring.....	1
10	01-402275-00403	Shim.....	1
11	01-410151	Sleave - Bearing (3/8).....	1
12	01-407322-00012	Cam - Roller.....	1
13	01-407322-00010	Pin - Eccentric.....	1
14	01-407322-0007C	Block - Front.....	2
15	01-403475-00753	Cover - Front (White).....	1
16	01-402175-00423	Cap Screw 1/4 x 3/8 Slotted Rd. Hd., Type TT.....	1
17	01-402275-00304	Washer.....	1
18	01-402275-03055	Lockwasher.....	1
19	01-402175-00200	Cap Screw 1/4-28 x 1/2 Hex Hd.....	1
20	01-402275-01140	Pin - Groove.....	1
21	01-402175-00438	Handle - Frame Operating.....	1
22	01-402275-01140	Pin - Groove.....	1
23	01-402275-03047	Lockwasher #10 Internal.....	2
24	01-402175-03431	Mach. Screw 8-32 x 3/8 Truss Hd.....	2
25	01-402175-00423	Cap Screw 1/4 x 3/8 Slotted Rd. Hd., Type TT.....	1
26	01-403375-01401	Pin.....	2
27	01-402175-07030	Nut.....	2



SWITCH MECHANISM

SWITCH MECHANISM

ILLUS.	PART NO.	NAME OF PART	AMT.
PL-59514			
1	01-404175-00421	Cord (Switch to Motor).....	1
2	01-402175-00186	Screw Slotted Rd. Hd.....	1
3	01-407325-0005E	NLA - Obsolete--Clamp.....	1
4	01-402175-00120	Nut 5/16-24 Hex.....	1
5	01-40000A-7325C	Lever Assy. (Operating Switch) (Incls. Item 40).....	1
6	01-402275-00405	Knob - Operating Rod.....	1
7	01-403375-01008	Rod - Operating.....	1
8	01-402275-00267	E-Ring.....	1
9	01-402275-00481	Grommet - Rubber (1/4 In.).....	1
10	01-402275-00481	Grommet - Rubber (1/4 In.).....	1
11	01-402275-03041	Washer.....	1
12	01-402175-00224	Cap Screw Hex Socket Hd.....	1
13	FE-021-21	Strain Relief.....	1
14	01-404175-00031	Cord - Plug To Switch (110 V.).....	1
15	01-402175-03631	Mach. Screw 8-32 x 3/8 Flat Hd.....	1
16	01-403875-00159	Cover - Switch.....	1
17	01-402275-01087	Lockwasher 1/2 Internal.....	1
18	01-402675-00617	Switch - Toggle.....	1
19	01-402275-00415	Lockwasher.....	1
20	01-400942-00030	Shim.....	1
21	01-402275-00415	Lockwasher.....	1
22	01-404875-00056	Kit - Operating Switch (Individual parts are not available.).....	1
23	01-403675-00219	Clamp - Mercury Switch.....	1
24	01-400942-00030	Shim.....	1
25	01-402275-00415	Lockwasher.....	1
26	01-402175-01322	Mach. Screw 6-32 x 1/2 Pan Hd.....	1
27		Switch - Mercury (Part no longer available, order Item 22).....	1
28	01-402275-03430	Pin - Cotter.....	1
29	01-402275-00227	Washer.....	1
30	01-402175-00203	Mach. Screw Rd. Hd.....	1
31	NS-011-23	Nut 10-32 Hex (SST).....	1
32	01-403375-01205	Nut 3/8-16 Pivot Bushing.....	1
33	NS-011-23	Nut 10-32 Hex (SST).....	1
34	01-407325-0008A	Latch - Operating Lever.....	1
35	01-408670	Spring.....	1
36	01-408671	Head Screw.....	1
37	01-402375-00159	Spring - Extension.....	1
38	01-403475-00863	Bracket - Spring.....	1
39	NS-011-23	Nut 10-32 Hex (SST).....	1
40	01-402375-00191	Bushing - Bronze.....	1
41	01-402675-00647	Guard - Toggle Switch.....	1
42	01-402675-00053	Light - Pilot.....	1
43	01-402675-00024	Connector - Wire.....	1
44	01-404975-09165	Kit - Operating Lever (Incls. Items 6 & 7).....	1
45	01-412343	Pin - Groove.....	1
46	01-403475-00868	Bracket - Circuit Breaker.....	1
47	01-402675-00584	Circuit Breaker (8 Amp.).....	1
48	01-402675-00583	Circuit Breaker (4 Amp.).....	1
49	01-404175-00029	Switch (15 Amp.).....	1




PL-59510

BLADE AND FRAME ASSEMBLY

BLADE AND FRAME ASSEMBLY

ILLUS. PL-59510	PART NO.	NAME OF PART	AMT.
1	01-408594	Sleave - Revolving Oiler.....	2
2	01-407322-0001E	Bushing (5/8).....	2
3	01-403375-00990	Nut - Knife Tension.....	1
4	01-403475-00656	Tab - Knife Lug.....	1
5	01-402175-00349	Mach. Screw #10 x 1/2 Flat Hd.....	1
6	01-404975-00183	Kit - Knife Lug (1/2 In.).....	1
7	01-404975-00182	Kit - Knife Lug (7/16 In.).....	1
8	01-404975-00181	Kit - Knife Lug (3/8 In.).....	1
9	01-404975-00478	NLA - Obsolete--Kit - Upper Knife Lug (3/4 In.).....	1
10	01-404975-00479	Kit - Lower Knife Lug (3/4 In.).....	1
*11	01-404575-00693	Knife Assy.....	AR
*12	01-404575-00968	Knife Assy. (SST).....	AR
13	01-402175-00349	Mach. Screw #10 x 1/2 Flat Hd.....	1
14	01-407322-0001F	Bushing - Oilite.....	1
15	01-402175-00233	Cap Screw 1/4-28 x 3/4 Hex Socket Hd.....	1
16	01-402275-03055	Lockwasher.....	1
17	01-409463-00060	Washer.....	1
18	01-402175-03061	Cap Screw 5/16-18 x 5/8 Hex Hd.....	1
19	01-409463-00060	Washer.....	1
20	01-402275-03055	Lockwasher.....	1
21	01-402175-00233	Cap Screw 1/4-28 x 3/4 Hex Socket Hd.....	1
22	01-400270-25388	Bracket.....	1
23	01-400270-25389	Strap - Bracket.....	1
24	01-425390-00006	Shim.....	2
25	01-400270-25387	Bar - Slide.....	1
26	01-425390-00006	Shim.....	2
27	01-404675-00016	Rail - Knife (Left).....	1
28	01-404675-00017	Rail - Knife (Right).....	1
29	01-407322-0001F	Bushing - Oilite.....	1
30	01-404975-00197	Frame Assy. - Upper Knife (3/8).....	1
31	01-404975-00199	Frame Assy. - Upper Knife (7/16).....	1
32	01-404975-00201	Frame Assy. - Upper Knife (1/2).....	1
33	01-404975-00654	Frame Assy. - Upper Knife (3/4).....	1
34	01-404975-00198	Frame Assy. - Lower Knife (3/8).....	1
35	01-404975-00200	Frame Assy. - Lower Knife (7/16).....	1
36	01-404975-00202	Frame Assy. - Lower Knife (1/2).....	1
37	01-404675-00655	Frame Assy. - Lower Knife (3/4).....	1

* (See chart on graphic for quantities.)



PL-59512

CAMS, LINKAGE, AND SCRAP PAN

CAMS, LINKAGE, AND SCRAP PAN

ILLUS. PL-59512	PART NO.	NAME OF PART	AMT.
1	01-408589	Screw - Shoulder.....	1
2	01-407324-0005A	Cam Link - Connecting.....	1
3	01-400470-25358	Cam Assy. (RH & LH).....	1
4	01-402175-00137	Thin Nut 3/8"-24, 0.227 - 0.210" thick.....	1
5	01-408587	Bolt Hex Hd.....	1
6	01-408587	Bolt Hex Hd.....	1
7	01-402175-00137	Thin Nut 3/8"-24, 0.227 - 0.210" thick.....	1
8	01-400470-25358	Cam Assy. (RH & LH).....	1
9	01-407324-0005A	Cam Link - Connecting.....	1
10	01-408589	Screw - Shoulder.....	1
11	01-408588	Bolt Hex Hd.....	1
12	01-402175-00189	Mach. Screw 10-32 Truss Hd.....	1
13	01-407324-0000D	Bracket - Bread Trough Locating.....	1
14	01-407304-0002F	Bracket - Support.....	1
15	01-407324-00004	Bar - Bread Trough Pivot (Undrilled).....	1
16	01-407304-0002F	Bracket - Support.....	1
17	01-407324-0000D	Bracket - Bread Trough Locating.....	1
18	01-402175-00189	Mach. Screw 10-32 Truss Hd.....	1
19	01-408588	Bolt Hex Hd.....	1
20	01-407324-0004A	Spacer.....	1
21	01-402275-00159	Pin - Taper #2 x 1 (Previous Construction).....	2
22	01-402275-01145	Pin - Groove 3/16 x 1 (Current Construction).....	2
23	01-402175-00210	Mach. Screw Hex Hd.....	1
24	01-402275-03055	Lockwasher.....	1
25	01-402175-00198	Set Screw 1/4-28 x 5/16.....	2
26	01-409201	Pin - Taper (Previous Construction).....	2
27	01-402275-01143	Pin - Groove 3/16 x 3/4 (Current Construction).....	2
28	01-402175-00198	Set Screw 1/4-28 x 5/16.....	1
29	01-403775-00080	Arm - Operating Switch.....	1
30	01-407322-0000A	Handle - Operating.....	1
31	01-402275-00159	Pin - Taper #2 x 1.....	1
32	01-403475-01029	Support - Scrap Pan.....	1
33	01-402275-03045	Lockwasher #10 Spring.....	1
34	01-402175-00189	Mach. Screw 10-32 Truss Hd.....	1
35	01-402175-03441	Mach. Screw 10-24 x 3/8 Truss Hd.....	2
36	01-402275-00405	Knob.....	1
37	01-403475-00749	Plate - Scrap Pan Front (White).....	1
38	01-402175-05040	Nut 10-24 Hex.....	2
39	01-404675-00798	Pan Assy. - Scrap (White).....	1
40	01-402175-00189	Mach. Screw 10-32 Truss Hd.....	1
41	01-402275-03045	Lockwasher #10 Spring.....	1
42	01-403475-01029	Support - Scrap Pan.....	1
43	01-402275-03041	Washer.....	1
44	01-402275-03045	Lockwasher #10 Spring.....	1
45	01-402175-03441	Mach. Screw 10-24 x 3/8 Truss Hd.....	1
46	01-402275-03041	Washer.....	2
47	01-402275-03045	Lockwasher #10 Spring.....	2

