





IRCS4 QUICK OPERATING GUIDE

CONTROLS

▲ AND ▼ BUTTONS

Used to change between menu products and to move between selections and make adjustments in other menus.

MERGE

Used to match the product setting of both conveyors to the product of the side pressed.

REVERSE

Used to stop conveyor for melting/broiling for a set time. When finished, the conveyor automatically reverses and stops again. Press "REVERSE" again to return to previous product settings.

DARKER/LIGHTER

Used to adjust conveyor speed for longer/shorter toasting time.

ACCESSING FUNCTIONS

COOLDOWN MODE

Accessed by holding the "DARKER/LIGHTER" button and both ▼ buttons.

STANDBY MODE

Accessed by holding the "DARKER/LIGHTER" button and right **b**utton.

SETUP MENU

Accessed by holding the "DARKER/LIGHTER" button. This menu can be used to edit a product's name and settings.

EDITING PRODUCT NAME

Press the left "REVERSE" button on the product name. Use the right ▲ and ▼ buttons to cycle through characters and the left ▲ and ▼ buttons to move selection from character to character. Spaces cannot be used and the name can be up to a maximum of nine [9] characters. Press the "DARKER/LIGHTER" button to save and exit.

EDITING SETTINGS

Selected product can be changed using the ▲ and ▼ buttons on the left side. The right merge and reverse buttons are used to cycle between the other settings. The number values can be changed using the right side ▲ and ▼ buttons. Press the "DARKER/LIGHTER" button to save and exit.