

XpressChef™

Panini Press Accessories

Panini sandwiches toasted to perfection without a hood

- Non-stick cooking surface
- Height-adjustable upper grill plate
- Easy to clean
- Removable
- 2 available styles—for XpressChef™ XC 3i or XC 4i High Speed Ventless Ovens



	Panini Press Accessory for XC 3i MRX Ovens	Panini Press Accessory for XC 4i MXP Ovens
ITEM#	PRS10R <i>(pictured left)</i>	PRS10 <i>(pictured above)</i>
HIGHLIGHTS	<ul style="list-style-type: none">• 2 Adjustable upper grill plate height levels• Upper open grooved grill plate• Lower Reversible grill plate (grooved/solid)	<ul style="list-style-type: none">• 3 Adjustable upper grill plate height levels• Upper and Lower Reversible grill plates (grooved/solid)

ACP
INC.
Accelerated Cooking Products