


Spare parts list for DCB36/DCB36-48



Spare parts list for DCB36

Item NO.	Part NO.	Description
1	C0-000-COD00029	Wire-type condenser
2	C0-000-FAN00010	Evaorator fan
3	C0-000-FIL00002	Filter
4	B0-000-OTR00004	Filter base
5	A0-078-OTR00001	Outer drain pan for DCB series
6	C0-000-COM10001	Compressor
7	C0-000-FAN00010	Evaorator fan
8	C0-000-EVA00051	Evaporator
9	A0-078-OTR00002	Inner drain pan
10	C0-000-FET00002	Castor, 5", no brakes
11	C0-000-FET00001	Castor, 5", with brakes
12	A0-078-OTR00003	Control pannel for DCB series
13	C0-000-OTR00002	Waterproof box for thermostat
14	C0-000-CTR00001	Digital controller
15	A0-078-OTR00004	Wallrail, back
16	A0-078-OTR00005	Wallrail, front/left
17	A0-078-OTR00006	Wallrail, front/right
18	A0-078-DOR00001	Foaming drawer
19	B0-078-DOR00001	Drawer gasket
20	C0-000-OTR00028	Set of sliding rails, left
21	C0-000-OTR00029	Set of sliding rails, right
22	A0-078-OTR00007	Horizontal supporter for GN pan
23	A0-078-OTR00008	Vertical supporter for GN pan
24	C0-000-JBX00001	Junction box, ET0301G
25	C0-000-TSS00003	Temperature sensor
26	C0-000-COR00001	Power cord set, NEMA5-15P