STACKING DETAILS:

READ THE MANUAL BEFORE PROCEEDING WITH THESE SPECIFIC INSTRUCTIONS.

- REMOVE FRONT PANEL (LATCHES)
- REMOVE FINGERS, BAFFLES & CONVEYOR ASSEMBLY (NO TOOLS) TO LIGHTEN THE OVEN AND REMOVE PARTS THAT COULD SHIFT DURING STACKING.
 DEMOVE TOP DANEL OF THE POTTOM OVEN.
- REMOVE TOP PANEL OF THE BOTTOM OVEN IN THE STACK (2 screws each front & back)
- REMOVE HOLE PLUGS IN TOP PANEL (bottom oven only)
- ATTACH TOP PANEL OF BOTTOM OVEN DIRECTLY TO BOTTOM OF TOP OVEN FOUR SUPPLIED BOLTS ATTACHMENT TO THE OVEN IN PLACE OF THE LEG HOLES
- PREPARE THE BOTTOM OVEN BY ATTACHING LEGS AND PLACING IT SECURELY ON A CART OR COUNTERTOP
- CAREFULLY LIFT THE PREPARED TOP OVEN ONTO THE SECURE BOTTOM OVEN EVEN WITH ALL LOOSE PARTS OFF, THE OVEN IS HEAVY (150 POUNDS) AND CAN CAUSE SERIOUS INJURY.
- REATTACH THE SCREWS FRONT & BACK
- REASSEMBLY ALL THE LOOSE PARTS



