



Mid Rim Plate
9117C1180 D 11 3/4"
9117C1170 D 11 1/4" (7 1/2" Well)
 (Plate Cover 5379S784)
9117C1181 D 10 5/8"
9117C1182 D 10"
9117C1183 D 9"
9117C1184 D 8"
9117C1185 D 6 1/4"



Gourmet Plate
9117C1171 D 11 1/4" (6" Well)
 (Plate Cover 5379S784)



Gourmet Plate
9117C1172 D 11 1/4" (4 3/4" Well)
 (Plate Cover 5379S784)




Gourmet Accent Plate
9117C1177 D 7 1/4"



Gourmet Coupe Plate
9117C1173 D 11"



Oval Plate
9117C1190 L 13" W 10 1/4"



Gourmet Rim Coupe Bowl
9117C1174 D 11 1/4" H 1 3/4" (10 oz)
 (Plate Cover 5379S784)



Gourmet Deep Coupe Bowl
9117C1175 D 11 1/4" H 2" (10 oz)
 (Plate Cover 5379S784)



Deep Rim Bowl
9117C1191 D 12 1/2" H 3 1/2" (12 oz)



Gourmet Deep Rim Bowl
9117C1176 D 11 1/4" H 1 3/4" (10 oz)
 (Plate Cover 5379S784)
 Rim Soup Bowl
9117C1214 D 9 1/2" (12 oz)



new
 Bowl
9117C1211 D 6" H 3" (27 oz)
9117C1212 D 5 1/4" H 2 1/2" (17 oz)
9117C1215 D 4 1/2" H 2 1/2" (10 oz)
9117C1213 D 4" H 2 1/4" (7 oz)
 Saucer
9117C1192 Double Well D 6"
 (Fits C1212, C1213)



Bowl
9117C1210
 D 6 1/2" H 2" (7 oz)



Unhandled Stack Soup Cup
9117C1202 D 4 1/4" H 2 1/4"
 (10 oz)
 Saucer
9117C1192 Double Well D 6"



new
 Stack Cup
9117C1200 L 4 1/4" H 2 5/8" (7 1/2 oz)
9117C1205 L 3 3/8" H 1 7/8" (3 oz)
 Saucer
9117C1192 Double Well D 6" (Fits C1200)
9117C1193 Double Well D 4 5/8" (Fits C1205)



Can Cup
9117C1201 L 4 1/2" H 2 5/8" (8 oz)
 Saucer
9117C1192 Double Well D 6"



Mug
9117C1203 L 4 3/4" H 3 1/2" (10 oz)
 Saucer
9117C1192 Double Well D 6"



Jug
9117C1204 L 5" H 4 3/8" (5 oz)