



**Angled Bowl**  
**11070562** D 8" (24 oz)  
**11070563** D 6" (10 oz)  
**11070564** D 4" (2 1/2 oz)



**Scoop Bowl**  
**11070574** L 6 1/2" (9 oz)  
**11070583** L 4 1/2" (2 1/2 oz)  
**11070584** L 3 1/2" (1 oz)



**Large Soup Bowl**  
**11070558** D 4 1/2" H 3 1/2" (21 oz)  
**Saucer Double Well**  
**11010225** D 6 1/2"



**Tilt Pot**  
**11070599**  
 D 3 1/2" H 3"  
 (8 oz)



**Taster Bowl**  
**11070576** D 5"  
 (10 1/4 oz)



**Taster Dip**  
**11070575**  
 D 2 1/2"  
 (1 3/4 oz)



**Sauce Pot**  
**11070608**  
 D 2 1/2" H 3"  
 (6 oz)



**Pourer**  
**11070557**  
 W 3" H 2 7/8"  
 (3 oz)



**Quench Mug**  
**11010590** L 5" H 5 1/8" (16 oz)  
**11010591** L 4 1/2" H 4 3/4" (12 oz)  
**11010592** L 4 1/4" H 4 3/8" (10 oz)  
**11010593** L 4 1/8" H 4 1/8" (8 oz)  
**11010594** L 3 1/8" H 2 7/8" (3 oz)



**Wooden Charger Plate**  
**6515T345** Light L W 11 7/8" (Inner Wells L 7 1/2" W 2")  
**6515T346** Dark L W 11 7/8" (Inner Wells L 7 1/2" W 2")  
**Creations Glass Charger Plate**  
**6506G231** L W 12" (Inner Wells L 7 1/2" W 2")