



new



Chop Plate
4410RF024 D 12"



Banquet Rim Plate
4410RF001 11" (7" Well)
(Plate Cover 5379S801)
(Plate Cover 5379S796)
4410RF003 D 10"
4410RF004 D 9"
4410RF005 D 8"
4410RF006 D 6 1/2"



Wide Rim Presentation Plate
4410RF002 D 11" (5 1/2" Well)
(Plate Cover 5379S801)



Deep Presentation Plate
4410RF009 D 11" H 1 5/8" (7 3/4" Well)
(Plate Cover 5379S801)



Wide Rim Pasta Plate
4410RF017 D 11" H 1 7/8"
(6 1/2" Well) (16 oz)
(Plate Cover 5379S801)

new



Rectangle Tray
4410RF027 L 14 1/2" W 7"
(Plate Cover 5379S810)
4410RF028 L 11 3/8" W 7"
(Plate Cover 5379S811)

new



Square Tray
4410RF025 LW 9 7/8"
(Plate Cover 5379S812)
4410RF026 LW 8 1/2"
(Plate Cover 5379S813)



Rim Presentation Bowl
4410RF007 D 11" H 2 1/8" (10 oz)
(Plate Cover 5379S801)



Wide Rim Presentation Bowl
4410RF010 D 11" H 2" (5 1/2" Well)
(Plate Cover 5379S801)



Rim Soup Bowl
4410RF008
D 9 1/2" H 1 3/4" (14 oz)



Oatmeal Bowl
4410RF011
D 6 1/2" H 2" (16 oz)



Rim Fruit
4410RF012
D 5 1/8" H 1 1/2" (5 oz)



Stack Soup Cup
4410RF014 D 4 1/4" H 2 3/8" (10 oz)
Saucer
4410RF016 D 5 7/8"



Sugar/Bouillon Cup
4410RF013 D 4" H 2 1/4" (8 oz)
Saucer
4410RF016 D 5 7/8"



Stack Cup
4410RF015 D 4 1/8" H 2 1/2" (8 oz)
Saucer
4410RF016 D 5 7/8"



Low Coffee Cup
4410RF018 L 5 1/4" W 4" H 2 5/8" (10 1/2 oz)
Saucer
4410RF016 D 5 7/8"



Can Coffee Cup
4410RF019 L 4 1/2" W 3 3/8" H 2 1/2" (10 oz)
Saucer
4410RF020 D 6 1/8"



Creamer
4410RF021
L 3 7/8" W 2 5/8" H 3 1/4"
(6 3/4 oz)



Sugar Bowl
4410RF022
D 2 3/4" H 2 1/4"
(4 1/2 oz)

