

IMPORTANT SAFEGUARDS

1. Read all instructions before using appliance.
2. When using electrical appliances, basic safety precautions should always be followed.
3. Do not touch the metal surface when in use, as it may be hot. Use the handles on the lid and body, instead.
4. To prevent fire and electric shock, do not immerse cord, or unit in water or other liquid.
5. Close supervision is necessary when any appliance is used near or around children.
6. Unplug unit when not in use and before cleaning.
7. Do not use if the unit is damaged. Consult manufacturer.
8. The use of any accessories or attachments not made specifically for this unit may result in fire or electric shock and injury.
9. This unit is not for outdoor use.
10. Do not let cord hang over the edge of the table or counter. Do not let cord touch hot surfaces.
11. Do not place unit on or near stoves or other heated appliances.
12. Always attach cord to appliance first, and then plug cord into wall outlet. Always turn unit off before unplugging cord from outlet.
13. Do not use appliance for anything other than its intended use.
14. Be sure the lid is fastened properly before brewing or heating water.
15. Scalding may occur if the lid is removed while unit is on.
16. When used to heat water only it is not necessary to use the filter basket and spray tube.
17. Use only soft cloth to clean the boiler.

Warranty:

Due to the specialty nature of this item and lack of parts in the United States, Town Food Service Equipment Co., Inc. ("Town") will warrant this product only on a limited basis. We will repair any unit found defective due to faulty workmanship or materials within **three** months of invoice date provided Town has the parts available to it from the overseas factory. Units requiring repair must be returned prepaid to Town only after obtaining an Return Goods Authorization (RGA) number from customer service by calling (718)388-5650. Units repaired under warranty will be returned prepaid. We cannot send replacement units for defective units, nor can Town be responsible for any losses resulting from this unit.



COFFEE PERCOLATOR

Owner's Manual



model no. 39106, 39109, 39115

NOTE

Read instructions in its entirety prior to using this unit. Call our customer service department at (718) 388-5650 or your dealer if you have any questions regarding its use.

Town Food Service Equipment Co., Inc.

72 Beadel Street, NY 11222

(718)388-5650 (800)221-5032 FAX (718)388-5860

Specializing in Chinese foodservice since 1929

Congratulations on your purchase of the Town Food Coffee Boiler!

Please read the complete instruction manual before using, and keep for future reference.

When using this and all electric appliances, basic safety precautions should always be followed.

General Information:

- Make sure the power complies with the voltage and plug the appliance into a grounded socket before use. Make sure this unit has a dedicated socket.
- Always use the appliance on a dry, firm surface, away from humidity and high heat. Failure to do so may result in unit failure.
- Fill the tank with cold water before plugging in the unit. Do not let the unit run out of water while it is on or the unit could be damaged.
- Water tank and heating element should be cleaned daily. If not cleaned often, deposits can build up and affect the performance of the unit and could cause power to cut out. Always unplug the unit before cleaning. Never immerse the appliance in water, as this could cause electric shock and/or destroy the unit.
- Do not use abrasive cleaning detergents. Make sure there is no residue from cleaning products or other foods/liquids on the heating elements. It can cause the unit to overheat.
- Be careful in handling the unit while it is on. The body and cover may get very hot and can cause burns if not handled properly.
- The unit must be unplugged before it can be reset. Once the appliance has cooled, press the reset button before turning it back on. If you do not do this, the light will come on, but the unit will not become operational, due to a thermal cut off switch to prevent overheating.
- Turn off the power and unplug the cord after use.
- If you have any problems, consult the manufacturer. Phone number: 1-800-221-5032.

Installation:

- Clean and dry the filter basket, cover and inner tank before first use.
- Fill the tank with cold water before use and never exceed the maximum water level.
- Put the spray tube into the middle hole of the coffee filter, and then put it into the middle hole of the inner tank. Make sure the spray tube sets firmly into the base. Put coffee grounds into the filter.
- Lock the top cover and turn on the power. The light will come on, if working properly.
- After boiling, the unit will keep the water warm. If the temperature drops, the unit will automatically re-heat it.
- After each use, clean inner tank with vinegar and water. If cared for properly, the unit will last a long time.
- Be sure the lid is secured properly before brewing or heating water.

SPECIFICATIONS	
For All Models	
VOLTAGE	120v
HERTZ	60 Hz
TEMPERATURE CONTROL	AUTOMATIC
VOLUME	
39106	6 L/ 40 cups
39109	9 L/ 60 cups
39115	15 L/ 100 cups

All Units come with a 60" cord, NEMA 5-15P