## **Performance Data Sheet**

Model: DP290-M

Use Replacement Cartridge(s): HF90 (Qty 2 cartridges)

The concentration of the indicated substances in water entering the system was reduced to a concentration less than or equal to the permissible limit for water leaving the system as specified in NSF/ANSI Standard 42 and Standard 53.



System tested and certified by NSF International against NSF/ANSI Standard 42 and Standard 53 for the reduction of substances as listed below according to Standard 42 and Standard 53.

Capacity: 108,000 gallons (408,824 liters)
Contaminant Reduction Determined by NSE testing

Substance Reduction	Average Influent	NSF/ANSI specified Challenge Concentration	Avg % Reduction	Average Product Water Concentration	Max Permissible Product Water Concentration	NSF/ANSI Reduction Requirements	NSF Test Report
Chlorine Taste and Odor	2.0 mg/L	2.0 mg/L ± 10%	97.3%	0.08 mg/L	N/A	≥ 50%	J-00018154
Nominal Particulate Class I, 0.5 ≤ 1.0 µm	3,833,333 pts/mL	At least 10,000 particles/mL	99.4%	19,883 pts/mL	N/A	≥85%	J-00047325
Cyst*	107,750 cysts/L	Minimum 50,000 cysts/L	99.99%	5 cyst/L	N/A	≥99.95%	J-00092653
Turbidity	11.5 NTU	11 ± 1 NTU	98.4%	0.19 NTU	0.5 NTU	N/A	J-00110254

<sup>\*</sup> Based on the use of Cryptosporidium parvum oocysts

#### FOR COMMERICIAL USE ONLY

Application Guidelines/Water Supply Parameters					
Service Flow	10 gpm ( 37.85 lpm)				
Water Supply	Potable Water				
Water Pressure	25 -125 psi (172 – 862 kPa)				
Water Temperature	40° F - 100° F (4.4° C - 38° C)				

It is essential that the manufacturer's recommended installation, maintenance and filter replacement requirements be carried out for the product to perform as advertised. See System Installation Manual for Warranty information.

**Note:** While the testing was performed under standard laboratory conditions, actual performance may vary.

Replacement Cartridge: HF90 (Qty 2 cartridges). For estimated costs of replacement elements please call 866.990.9785 or visit our website at www.3Mpurification.com

Parts and service available from:



3M Purification Inc.
400 Research Parkway
Meriden, CT 06450, U.S.A.
Tel 866.990.9785
203.237.5541
Fax 203.238.8701
www.3Mfoodservice.com
www.3Mpurification.com

3M is a trademark of 3M Company.
© 2013 3M Company. All rights reserved.
NSF is a trademark of NSF International
INSTR4408 0213

# **M**WARNING

To reduce the risk associated with ingestion of contaminants:

Do not use with water that is microbiologically unsafe or of unknown quality without adequate disinfection before and after the system. Systems certified for cyst reduction may be used on disinfected water that may contain filterable cysts.

EPA Establishment Number 070595-CT-001

### **CAUTION**

### To reduce the risk associated with property damage due to water leakage:

- Read and follow Use Instructions before installation and use of this system.
- Installation and use **MUST** comply with all state and local plumbing codes.
- Do not install if water pressure exceeds125 psi (862 kPa). If your water pressure exceeds 80 psi, you must install a pressure limiting valve. Contact a plumbing professional if you are uncertain how to check your water pressure.
- Do not install where water hammer conditions may occur. If water hammer conditions exist you
  must install a water hammer arrester. Contact a plumbing professional if you are uncertain how
  to check for this condition.
- **Do not** install on hot water supply lines. The maximum operating water temperature of this filter system is 100° F (38° C).
- Protect filter from freezing. Drain filter when temperatures drop below 40°F (4.4°C).
- The disposable filter cartridge must be replaced every 12 months at the rated capacity or sooner, if a noticeable pressure drop occurs.
- Flush 20.0 gallons through cartridge(s) before use (flush approximately 2 minutes).