



Ice Machine Cleaning & Sanitizing

HOSHIZAKI

KM-61BAH
KM-101BAH
KM-151BAH
KM-151BWH

The ice maker must be cleaned & sanitized at least once a year.

Cleaning Procedure

WARNING
DO NOT leave icemaker unattended when panels are off

AMMONIA Cleaners

1

Danger: Causes severe skin burns and eye damage. Observe precautions on bottle.

Hoshizaki ScaleAway

Water
5 fl. oz. 148 ml

1 GAL 3.8L

2

3

ICE ◀ OFF ▶ WASH

then... 3 min.

then... ICE ◀ OFF ▶ WASH

4

ICE ◀ OFF ▶ WASH

then...

5

6

7

ICE ◀ OFF ▶ WASH

then...

8

30 min.

then...

ICE ◀ OFF ▶ WASH

9

then... 4X

10

then...

ICE ◀ OFF ▶ WASH

11

3 min.

then...

ICE ◀ OFF ▶ WASH

12

5 min.

then...

ICE ◀ OFF ▶ WASH

13

14

15

16

17

18

19

20

Hoshizaki ScaleAway

Water
5 fl. oz. 148 ml

1 GAL 3.8L

21

22

SOLUTION

23

WATER

IMPORTANT:
Rinse parts and bin **THOROUGHLY** with water

Proceed to Sanitizing Procedure on reverse side

Sanitizing Procedure

WARNING
DO NOT leave icemaker unattended when panels are off

AMMONIA Cleaners

1

BLEACH
5.25% Sodium hypochlorite

Water
0.5 fl. oz. 15 ml or 1 Tbs
1 GAL 3.8L
200 ppm

2

Clean container

10 min.

3 then...

BLEACH

4

WATER

WATER

5

1
2

3
4

5
6
7
8

2X

6

BLEACH
5.25% Sodium hypochlorite

Water
0.5 fl. oz. 15 ml or 1 Tbs
1 GAL 3.8L
200 ppm

7

BLEACH

10 min.

8 then...

ICE ◀ OFF ▶ WASH

15 min.

9 then...

ICE ◀ OFF ▶ WASH

10

WATER

11

WATER

12

ICE ◀ OFF ▶ WASH

13

14

Discard first batch

CLEANING SCHEDULE

- Scoop Dish soap, rinse well
 - Water Filters Check psi; change if req'd
 - Exterior Dish soap & damp cloth
 - Bin Door/Top Kit Warm water & clean cloth
 - Ice Maker/Bin *Follow these instructions*
 - Water Supply Inlet Clean inlet screen
 - Condenser Inspect. Clean with brush
 - Water Hoses Inspect. Replace if req'd
- DAILY | ● MONTHLY | ● YEARLY

THIS IS A QUICK REFERENCE GUIDE ONLY. FOR COMPLETE CLEANING AND SANITIZING INSTRUCTIONS DOWNLOAD OUR COMPLETE INSTRUCTION MANUAL.



Download complete instruction manual

Type in the model number of your ice machine (including dashes) to download manuals

Tech Support:

1.800.233.1940

hoshizakiamerica.com/support