3M™ Water Filtration Products

SPEC# ______



application:

MULTIPLE EQUIPMENT

High Flow Series

Dual Flow Manifold System DIDF265-CL

3M™ Water Filtration Products DIDF265-CL dual flow water filtration system helps provide consistent high quality water for the multiple applications of cold beverages and ice. Two separate streams exit the manifold. The first stream supplies cold beverage equipment and the second stream supplies the ice machine.

- The stream to the cold beverage equipment combines chloramines, sediment, chlorine taste and odor reduction.
- The stream to the ice machine reduces sediment and particulates. Chloramines and/or chlorine are not reduced from this stream to preserve their disinfectant properties. Scale inhibition media is added to reduce the hard scale effects of calcium and magnesium ions.

PRODUCT BENEFITS

- One system for dedicated ice and cold beverage applications that simultaneously supplies high quality water for beverage dispensers and ice machines.
- A dedicated non-carbon containing cartridge reduces sediment and particulates while adding a scale inhibition medium for ice machines. The inlet water's chlorine/chloramines content is unaffected for the reduction of biofilm in the ice machine.
- Sanitary Quick Change (SQC) encapsulated cartridge design allows for fast and easy cartridge change-outs with a 1/4 turn.
- 3/4" FNPT horizontal inlet and outlet ports allow direct or easily adaptable connections to existing plumbing lines.
- Manifold includes outlet check valves and vent valve.

PRODUCT SPECIFICATIONS

Model Number	Part Number	Reduction Claims	Nominal Micron Rating	Beverage Capacities and Flow Rates	Application	Replacement Cartridge	Sizing
DIDF265-CL	56276-02	Sediment, Chloramines, Chlorine Taste and Odor, Scale ¹	5.0	14,000 gallons @ 4.2 gpm 16,000 gallons @ 3.34 gpm 30,000 gallons @ 2.0 gpm		DIDF265-CL CARTPAK: 56138-26 (HF65-CL (QTY 2) & HF65-S-SR5 (QTY 1))	For simultaneous operation of carbonators and ice machines

¹ Tested and verified by manufacturer's laboratory



Dual Flow Manifold System DIDF265-CL

3M™ Water Filtration Products

SPEC#	
QUANTITY	
MODEL NUMBER	
DADT NIIMDED	

23½" (59.1cm) (18¾" (47.6 cm)

SPECIFICATIONS

- System includes a three cartridge dual outlet port manifold with built-in inlet and outlet pressure gauges, inlet water shut-off valve, outlet check valve, mounting brackets and the cartridge filters.
- Inlet and outlet plumbing connections are 3/4" FNPT.
- · Filter cartridges are o-ring seal type.
- System maximum operating pressure of 125 psi (862 kPa) and operating temperature of 100°F (37.8°C).
- Beverage filter cartridges incorporate a carbon block filtration medium. Ice filter cartridge includes a scale inhibition medium.
- · System materials are NSF Standard 42 and/or FDA CFR-21 compliant.
- Cartridges are sanitary in design, requiring no contact with the filter media during cartridge change-out.
- Filter cartridges require no pre-activation.
- . NSF Performance Data Sheet (PDS) is included for the replacement filter.

IMPORTANT: INSTALLATION TIPS

These installation tips are for informational purposes only and are not intended to be used as actual installation instructions. CAUTION: To reduce the risk associated with property damage due to water leakage:

- Read and follow Use Instructions before installation and use of this system.
- · Installation and use MUST comply with all state and local plumbing codes.
- Protect from freezing, remove filter cartridge when temperatures are expected to drop below 40°F (4.4°C).
- Do not install on hot water supply lines. The maximum operating water temperature of this filter system is 100°F (37.8°C).
- Do not install if water pressure exceeds 125 psi (862 kPa). If your water pressure exceeds 80 psi (552 kPa), you must install a pressure limiting valve. Contact a plumbing professional if you are uncertain how to check your water pressure.
- Do not install where water hammer conditions may occur. If water hammer conditions exist
 you must install a water hammer arrester. Contact a plumbing professional if you are uncertain how to check for this condition.
- The disposable filter cartridge MUST be replaced every 12 months, at the rated capacity
 or sooner if a noticeable reduction in flow rate occurs.

$\underline{\wedge}$ WARNING: To reduce the risk associated with the ingestion of contaminants:

 Do not use with water that is microbiologically unsafe or of unknown quality without adequate disinfection before or after the system.

3M Purification Inc. recommends regularly scheduled maintenance and replacement of the filter cartridge in order for the product to perform as advertised/sold. 3M Purification Inc. shall not be liable for system failures due to improper maintenance.

LIMITED WARRANTY

3M Purification Inc. warrants this Product (excluding disposable filter cartridges(s) or membranes(s)) will be free from defects in material and manufacture for five (5) years from the date of purchase. The disposable filter cartridge or membrane is warranted from defects in material and manufacture for a period of one (1) year from the date of purchase. This warranty does not cover failures resulting from abuse, misuse, alteration or damage not caused by 3M Purification Inc. or failure to follow installation and use instructions. No warranty is given as to the service life of any filter cartridge or membrane as it will vary with local water conditions and water conditions and water conditions and water conditions. APPURIFICATION INC. MAKES NO OTHER WARRANTIES OR CONDITIONS, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OR CONDITION OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR ANY IMPLIED WARRANTY OR CONDITION ARISING OUT OF A COURSE OF DEALING, CUSTOMER OR USAGE OF TRADE. If the Product fails to satisfy this Limited Warranty during the warranty period, 3M Purification Inc. will replace the Product for refund your Product purchase price. This warranty does not cover labor. The membrane are remedy stated in this paragraph is Customer's sole remedy and 3M Purification Inc.'s exclusive obligation. For additional information, see the entire Limited Warranty located in the product Installation and Operating Instruction Manual.

Limitation of Liability. 3M Purification Inc. will not be liable for any loss or damage arising from this 3M Purification Inc. product, whether direct, indirect, special, incidental, or consequential, regardless of the legal theory asserted, including warranty, contract, negligence or strict liability. Some states and countries do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.



3M Purification Inc. 400 Research Parkway Meriden, CT 06450 U.S.A. Toll Free: 1.866.990.9785 Worldwide: 203.237.5541 Fax: 203.238.8701 yoww.3Mpurification.com