



Installation Instructions

Front Mounting Faucet

Model 934GN-LF, 934-10LF, 934-6LF and 934DJ-LF



934GN-LF



Installation of Front Mounting Faucet



1. Check to make sure elbows are tight to faucet body. Attach flexible supply lines to elbows. Hand tighten and maximum 1/4 turn with wrench. Feed supply lines through mounting holes.



2. Feed brass elbows attached to faucet body through mounting holes.



3. Hold faucet body firmly against backsplash aligned with screw holes as shown.



4. Secure faucet body with screws.



5. Completed faucet body installation.



6. Install faucet cover gasket as shown.




7. Insert top edge of cover into gasket groove. Align holes in top cover with openings in faucet body.



8. Press faucet cover into place so the faucet cover is fully seated within the rim in the gasket, as shown here.



9. Completed faucet cover installation. When seated correctly, the valve body threads protrude through cover as shown.



13. Secure faucet handles to the stem of the faucet valve assembly with screws provided. Red (Hot) on the left, Blue (Cold) on the right.



10. Faucet valve assembly. Turn handle stem to close the valve before installing. Attach handle to stem if needed to close valve.




14. Insert the bottom of the spout (goose neck spout shown) into center opening of faucet body.



11. Insert hot water valve assembly in the left opening in the faucet body. Note: Hot and cold valves are identified with "Hot" or "Cold" stamped in valve body. Turn chrome nut on top of valve to tighten. Note: Torque spec is 25 ft. lbs.



15. Secure the goose neck spout by turning the threaded retention collar clockwise until snug. Finish tightening with an adjustable wrench or channel locks. Do not overtighten.



12. Note valve seal must be seated in valve nut before assembly. Insert cold water faucet valve assembly in the right opening in the faucet body. Turn chrome nut on top of valve to tighten. Note: Torque spec is 25 ft. lbs.



16. Stand back and admire your fine work. Well done!



8300 West Good Hope Road • Milwaukee, WI 53223 •
Toll Free 800.558.5592 • Fax 414.353.7069 • www.perlick.com