






CLEANING INSTRUCTIONS

MDW Modular Dry Well

-  **USE ONLY A DRY CLOTH OR NON-SCRATCH PAD TO CLEAN THE ELEMENT.**
-  **IMPROPERLY EXPOSING THIS UNIT TO LIQUID, SUCH AS WATER, CAN PRESENT A SHOCK HAZARD AND DAMAGE THE UNIT.**
-  **DO NOT IMMERSE OR LET THE UNIT STAND IN WATER.**
-  **DO NOT HOSE DOWN THE UNIT OR THE TABLE/COUNTER IF THE UNIT IS ON THE TABLE/COUNTER.**
-  **KEEP AWAY FROM RUNNING WATER.**

BEFORE CLEANING, TURN THE CONTROL KNOB TO THE “OFF” POSITION AND ALLOW THE WARMER TO COOL COMPLETELY BEFORE PROCEEDING.

At each cleaning, inspect warmer flange-to-counter seal and inspect the warmer body for damage. If damage to the body exists, contact an authorized service agency before continuing use.

SUGGESTED CLEANING SUPPLIES

- i. Mild dish detergent and water
- ii. Surface sanitizer
- iii. Non-scratch scour pad
- iv. Clean cloth rag and/or sponge

DAILY CLEANING PROCEDURE

- i. Once the unit has completely cooled, remove any insets or pans to be washed separately. Remove the fan/element guard to be washed separately as well.
- ii. Use a non-scratch scouring pad to remove and deposits or food particles from the body of the unit. Gently, use the same type of pad on the element, making sure no cleaner or water is used on the element itself.
- iii. Wipe the body [excluding the element] down with a clean cloth or sponge and a mix of mild detergent and water. Rinse the cloth/sponge and then wipe down with clean water. Do not allow any excess liquid in the unit, just enough to moisten the sponge or cloth sufficiently for cleaning purposes.
- iv. Allow to dry and wipe with surface sanitizer. At this point, reinstall the clean fan/element guard and, when ready, any insets or pans that are to be used.