

VEGA HOOD

FOR SINGLE ALTAIR II STEAMER

INSTALLATION - OPERATION



MARKET FORGE



Telephone: (802) 658-6600 Fax: (802) 864-0183
www.marketforge.com

PN 14-0416 Rev B (12/15)

© 2015 - Market Forge

Installation & Operation

INSTALLATION

1. Unpack condenser hood and plumbing assemblies.
2. If the VEGA Hood was purchased separately from the Altair II steamer, you may need to remove the long copper vent pipe located in the rear of the steamer.
3. Place condenser hood on top of your Altair II, so that the L-feet sit over the corners of the steamer top panel.
4. Install the plumbing assemblies supplied as seen in "Figure 1" on page 3.
5. Place the drain hose into a collection bucket, or near a floor sink for condensed water. Remember to empty bucket occasionally.
6. Plug in the Condenser Hood to a standard 115V receptacle.
7. The Condenser Hood is now ready to operate.

OPERATION

Whenever the Steamer is in operation, turn the power switch on the front left side of the Condenser Hood to the 'ON' position.

At the end of the day when you power off the Steamer, turn the power switch on the Condenser Hood to the 'OFF' position as well.

For cleaning, simply wipe down the top and sides of the Condenser Hood with a damp cloth, or with stainless steel cleaner.

NOTE: Condenser Hood not evaluated for NFPA96. Not for use with cooking equipment handling grease products.



WARNING

WHEN CLEANING, DO NOT HOSE DOWN AS IT CONTAINS ELECTRICAL PARTS.



WARNING

THIS UNIT MUST BE SEALED IN PLACE UPON INSTALLATION.

Item	Description	Qty
1	Hose, 3/8 Neoprene, 18" Length	1
2	Tube, Flexible, 24" Length	1
3	Hose Clamp	2
4	Hose Clamp	5
5	Hose Barb 1/4" NPT made up of reducer Bushing 1/4" x 1/8" & Nipple, 1/8" x 1.5"	1
6	Hose Barb 1/2" NPT	4
7	Tee, 1/2"x1/2"x1/2"	2
8	Adapter, 3/4" Male NPT x 3/4" Hose, Brass	1
9	Elbow, 90°, Reducing	2
10	Nipple, 1/2" x 5" Brass	1
11	Hose, Drain, 3/8 Neoprene, 6' Length (Not Shown)	1
12	Hose, 3/8 Neoprene, 16" Length	1
13	Compression Fitting	1
14	Bushing, Reducing, 1" MNPT x 3/4" FNPT, Stainless	1
15	Adapter, 1/2" Male NPT x 3/4" Hose, Brass	1



Figure 1